

Please retain this sheet for future reference.

PARTS LIST:

- 1x Frame Assembly
- 1x Bin Bucket
- 1x Runner/Slider Assembly
- 1x Instruction Sheet

Installation

1. Position frame assembly min. 5mm from the door face.
2. Use four (KRB12) or six (KRB16) wood screws to fix bin frame to cabinet.

Note: It is important that the screws are in place as this adds to the rigidity of the frame.

Use small to medium bin liners.

How To Care For Your New Kimberley Waste Bin

1. Please make sure you thoroughly read and understand the installation instructions and follow them carefully.
2. For best results and longevity, always use a bin liner inside your waste bin.
3. Always make sure the liner is fitted without obstructing any of the waste bins moving parts.
4. Do not overload your waste bin.
5. Do not push the rubbish down to try to compact your waste.
6. Do not place heavy items on top of the bin lid. A Wire Basket (KWB01) is available to suit Waste Bin Models: KRB06, KRB06D, KRB08, KRB14, KRB14D, KRB15 & KRB15D.
7. Never try to close your waste bin with your feet.
8. Never force the waste bin closed.
9. Clean the interior and exterior of the waste bin regularly using a soft cloth and warm mild soapy water. Do not use harsh detergents.
10. Use a soft cloth to dry the waste bin after washing.
11. Thoroughly dry metal components to avoid rust and damage.
12. Do not use the bin outside or expose to the weather.
13. Do not place waste bin near a heater or hot device.

