

Please retain this sheet for future reference.

PARTS LIST:

- 1x Lid
- 1x Bag Holder
- 3x Rubber Strap
- 1x Benchtop Rim
- 1x Instruction Sheet

Installation

1. Mark desired position and cut Ø210mm hole through bench top.
2. Insert rim into bench top. Secure in place with Liquid Nails or similar adhesive.

Using Bin Liners

Place a suitable receptacle under the bench and/or use a bag if desired. Follow diagram below to fit bag. Use small to medium garbage bags.

1. Slip bag over bottom of bag holder.
2. Pinch bag tight around holder and fold excess around.
3. Stretch rubber strap and place over bag and bag holder to secure bag.
4. Slip bag through top of rim and feed through until bag holder sits on bottom edge of rim body.

Note: Support the bag in an appropriate sized bucket to avoid spillage.

Caring For Your Kimberley Waste Bin

1. Please make sure you thoroughly read and understand the installation instructions and follow them carefully.
2. For best results and longevity, always use a bin liner inside your waste bin.
3. Always make sure the liner is fitted without obstructing any of the waste bins moving parts.
4. Do not overload your waste bin.
5. Do not push the rubbish down to try to compact your waste.
6. Do not place heavy items on top of the bin lid. There is a Wire Basket (KWB01) available to suit Waste Bin Models: KRB06, KRB06D, KRB08, KRB14, KRB14D, KRB15 & KRB15D.
7. Never try to close your waste bin with your feet.
8. Never force the waste bin closed.
9. Clean the interior and exterior of the waste bin regularly using a soft cloth and warm mild soapy water. Do not use harsh detergents.
10. Use a soft cloth to dry the waste bin after washing.
11. Thoroughly dry metal components to avoid rust and damage.
12. Do not use the bin outside or expose to the weather.
13. Do not place waste bin near a heater or hot device.

